


Model No.DMP180 CORDLESS INFLATOR



Model No.DMP180 CORDLESS INFLATOR

| Tétel | Cikkszám   | Megnevezés                    | Átalakulás | Menny. | New/Old | Opc 1 | Opc 2 | Megjegyzés |
|-------|------------|-------------------------------|------------|--------|---------|-------|-------|------------|
| 001   | TE00000421 | DIGITAL DISPLAY               |            | 1      |         |       |       |            |
| 002   | TE00000204 | SCREW 3X14                    |            | 10     |         |       |       |            |
| 003   | TE00000420 | HOUSING ASSEMBLY              |            | 1      |         |       |       |            |
| D10   |            | INC. 20,21                    |            |        |         |       |       |            |
| 004   | TE00000338 | MAT                           |            | 2      |         |       |       |            |
| 005   | TE00000422 | FIXED BRACKET                 |            | 1      |         |       |       |            |
| 006   | TE00000352 | CLAMP                         |            | 1      |         |       |       |            |
| 007   | TE00000425 | MOTOR ASSEMBLY                |            | 1      |         |       |       |            |
| 008   | TE00000339 | RUBBER(CYLINDER)              |            | 2      |         |       |       |            |
| 009   | TE00000329 | SWITCH                        |            | 1      |         |       |       |            |
| 010   | TE00000327 | SCREW 3*10                    |            | 1      |         |       |       |            |
| 011   | TE00000328 | TRIGGER SPRING-FIXED<br>BLOCK |            | 1      |         |       |       |            |
| 012   | TE00000330 | SPRING                        |            | 1      |         |       |       |            |
| 013   | TE00000331 | SWITCH TRIGGER                |            | 1      |         |       |       |            |
| 014   | TE00000327 | SCREW 3*10                    |            | 2      |         |       |       |            |
| 015   | TE00000341 | POWER ON/OFF                  |            | 1      |         |       |       |            |
| 016   | TE00000342 | LED PCB                       |            | 1      |         |       |       |            |
| 017   | TE00000343 | TERMINAL PROTECTOR            |            | 1      |         |       |       |            |
| 018   | TE00000424 | BATTERY TERMINAL              |            | 1      |         |       |       |            |
| 019   | TE00000423 | PCB                           |            | 1      |         |       |       |            |
| 020   | TE00000420 | HOUSING ASSEMBLY              |            | 1      |         |       |       |            |
| D10   |            | INC. 3,21                     |            |        |         |       |       |            |
| 021   | TE00000426 | SWITCH LABEL                  |            | 1      |         |       |       |            |
| 022   | TE00000345 | AIR PIPE ASSEMBLY             |            | 1      |         |       |       |            |
| D10   |            | INC. 23                       |            |        |         |       |       |            |
| 023   | TE00000346 | BRITISH ADAPTER               |            | 1      |         |       |       |            |
| A01   | TE00000333 | SWIM RING ADAPTER             |            | 1      |         |       |       |            |
| A02   | TE00000335 | BALL ADAPTER                  |            | 1      |         |       |       |            |
| A03   | TE00000334 | FRENCH ADAPTER                |            | 1      |         |       |       |            |

Please order the parts with part number.

Print Date 2020/6/26