


Model No.DRV150 CORDLESS RIVET GUN



Model No.DRV150 CORDLESS RIVET GUN

Tétel	Cikkszám	Megnevezés	Átalakulás	Menny.	New/Old	Opc 1	Opc 2	Megjegyzés
001	319812-3	SCREW NUT 4.8		1				
002	213380-7	O-GYŰRŰ 24 6805BV		1				
003	127225-2	NOSEPIECE 4.8A ASSEMBLY		1				
D10		INC. 4,5						
004	213011-8	O-GYŰRŰ 7 213011-8*		1				
005	256217-5	CSAPSZEG 4 6702/03/04/05/06D		1				
006	327281-4	JAW CASE		1				
007	327279-1	HEAD 6.4		1				
008	199731-7	JAW 4.8 SET		1				
009	127475-9	JAW PUSHER 3.6 ASSEMBLY		1				
D10		INC. 49						
010	232586-8	COMPRESSION SPRING 7		1				
011	213265-7	O-GYŰRŰ 17 HR2400		1				
012	327285-6	JOINT 4.8		1				
013	140J44-9	FRONT HOUSING COMPLETE		1				
014	127221-0	BALL SCREW		1				
015	620A44-6	HALL IC CIRCUIT		1				
016	257457-8	RING 5		2				
017	310935-0	ROLLER SHAFT 4.8		1				
018	140E40-7	MAGNET HOLDER COMPLETE		1	*			
018-1	140T04-1	MAGNET HOLDER COMPLETE	<	1				
019	911008-8	TRAPÉZFEJŰ CSAVAR M3X8 1050DWA		1				
020	327284-8	TUBE 4.8		1				
021	458772-5	TUBE GUIDE A		1				
022	261161-3	FELT RING 8		1				
023	458773-3	TUBE GUIDE B		1				
024	233025-1	NYOMÓRUGÓ 2 233025-1*		1				
025	458774-1	SWITCH LEVER		1				
026	632M90-9	SWITCH UNIT		1				
027	162500-9	MANDREL CONTAINER COMPLETE		1				
028	140J46-5	SPUR GEAR 10 COMPLETE		1				
029	127222-8	GEAR ASSEMBLY		1				
030	266490-9	TAPPING SCREW PT 2X6		3				
031	632M66-6	CONTROLLER UNIT		1				
D10		INC. 35						
032	629373-8	STATOR		1				
033	619535-6	ROTOR		1				
034	652069-6	FLAT HEAD SCREW M3X6		3				
035	688164-6	LINE FILTER		1				
036	651379-8	SWITCH C3JW-1A-S		1				

Model No.DRV150 CORDLESS RIVET GUN

Tétel	Cikkszám	Megnevezés	Átalakulás	Menny.	New/Old	Opc 1	Opc 2	Megjegyzés
037	643874-2	TERMINAL		1				
038	855M09-3	DRV150 SERIAL NO. LABEL		1				
039	183L30-9	HOUSING SET		1				
C10	263005-3	GUMI CSAPSZEG 6 263005-3		2				
C20	252126-6	HEX. LOCKING NUT M4-7		2				
C30	931002-4	HEX. NUT M3		10				
D10		INC. 46						
040	265095-2	CSAVAR M3X20		10				
041	140J45-7	REAR HOUSING COMPLETE		1				
042	265490-6	IMBUSZCSAVAR		4				
043	310908-3	GUIDE PLATE L		1	*			
043-1	313297-5	GUIDE PLATE L	<	1				
044	310909-1	GUIDE PLATE R		1	*			
044-1	313298-3	GUIDE PLATE R	<	1				
045	620549-0	LED CIRCUIT		1				
046	183L30-9	HOUSING SET		1				
C10	263005-3	GUMI CSAPSZEG 6 263005-3		2				
C20	252126-6	HEX. LOCKING NUT M4-7		2				
C30	931002-4	HEX. NUT M3		10				
D10		INC. 39						
047	855M01-9	DRV150 NAME PLATE		1				
048	213891-2	O RING 14.5		1				
049	213054-0	O-GYŰRŰ 9 5014NB		1				
A01	251314-2	CSAVAR M4X12 LS0810/2012		1				
A02	346317-0	HOROG BDF456/BHP456		1				
A03	191C04-2	ACCESSORY SET B FOR 4.0		1				
C10	213011-8	O-GYŰRŰ 7 213011-8*		1				
C20	256217-5	CSAPSZEG 4 6702/03/04/05/06D		1				
C30	213054-0	O-GYŰRŰ 9 5014NB		1				
A04	199728-6	ACCESSORY SET FOR 3.2		1				
C10	213011-8	O-GYŰRŰ 7 213011-8*		1				
C20	256217-5	CSAPSZEG 4 6702/03/04/05/06D		1				
C30	213054-0	O-GYŰRŰ 9 5014NB		1				
A05	199729-4	ACCESSORY SET FOR 2.4		1				
C10	213011-8	O-GYŰRŰ 7 213011-8*		1				
C20	256217-5	CSAPSZEG 4 6702/03/04/05/06D		1				
C30	213054-0	O-GYŰRŰ 9 5014NB		1				
A06	191D57-7	GREASE SET		1				
A07B	***DC18RC	DC18RC FAST CHARGER		1				
D10		COMPO-PARTS						

Please order the parts with part number.

Print Date 2019/10/28

Model No.DRV150 CORDLESS RIVET GUN

Tétel	Cikkszám	Megnevezés	Átalakulás	Menny.	New/Old	Opc 1	Opc 2	Megjegyzés
A07C	***DC18RC	DC18RC FAST CHARGER		1				
D10		COMPO-PARTS						
A08B	197600-6	BATTERY BL1830B SET		2				
A08C	197600-6	BATTERY BL1830B SET		2				
A09B	450128-8	BATTERY COVER		1				
A09C	450128-8	BATTERY COVER		1				
A10B	821755-2	PLASTIC CASE		1				
C10	162315-4	LATCH		2				
A10C	821551-8	T2 KOFFER 396X296X210		1				
C10	453974-8	LATCH		4				
A11C	835A34-8	INNER TRAY		1				
A12C	819C50-0	DRV150RFJ INDICATION LABEL		1				
A13C	819C51-8	DRV150RFJ PLASTIC CASE LABEL		2				

Please order the parts with part number.

Print Date 2019/10/28