



Model DS4012 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	251441-5	- FLAT HEAD SCREW M6X22	1	PC.
002	193229-6	DRILL CHUCK S13	1	PC.
003	325494-1	SPINDLE	1	PC.
004	254211-1	KEY 5	1	PC.
005	285807-7	BEARING RETAINER 22-36	1	PC.
006	211206-7	BALL BEARING 6202LLB	1	PC.
007	266211-9	TAPPING SCREW 5X40	4	PC.
008	140620-9	GEAR HOUSING COMPLETE	1	PC.
	C10 263002-9	RUBBER PIN 4	1	PC.
009	211016-2	BALL BEARING 626LLB	1	PC.
010	226028-2	GEAR COMPLETE 7-41	1	PC.
011	261008-1	FIBER WASHER 6	1	PC.
012	257018-4	RING 15	1	PC.
013	221261-1	SPUR GEAR 47	1	PC.
014	961054-1	RETAINING RING S-14	1	PC.
015	256180-2	PIN 3	1	PC.
016	452066-0	GASKET	1	PC.
017	140619-4	GEAR HOUSING COVER COMPLETE	1	PC.
	C10 263002-9	RUBBER PIN 4	1	PC.
018	211031-6	BALL BEARING 608LLB	1	PC.
019	241850-6	FAN 60	1	PC.
020	518677-2	ARMATURE ASS'Y 115V	1	PC.
	D10	INC. 18,19,21,22		
021	681659-8	INSULATION WASHER	1	PC.
022	211031-6	BALL BEARING 608LLB	1	PC.
023	452063-6	BAFFLE PLATE	1	PC.
024	525871-9	FIELD ASS'Y 115V	1	
	C10 654100-4	RING TERMINAL	2	PC.
	C20 654555-3	CONNECTOR 34130	2	PC.
025	266095-5	TAPPING SCREW 5X55	2	PC.
026	643550-8	BRUSH HOLDER CAP 5-8	2	PC.
027	CB408	CARBON BRUSH CB-408 (195008-8)	1	SET
028	850P63-0	DS4012 NAME PLATE	1	
029	232260-8	LEAF SPRING	2	PC.
030	265995-6	TAPPING SCREW 4X18	4	PC.
031	188921-7	HANDLE SET	1	SET
	D10	INC. 32		
032	188921-7	HANDLE SET	1	SET
	D10	INC. 31		
033	140618-6	MOTOR HOUSING COMPLETE	1	PC.
	C10 643455-2	BRUSH HOLDER 6X9	2	PC.
034	265995-6	TAPPING SCREW 4X18	3	PC.
035	183A33-7	SWITCH HANDLE SET	1	
	D10	INC. 47		
036	682559-5	CORD GUARD 8	1	PC.
037	664064-4	POWER SUPPLY CORD AWG#18-2-2.5	1	PC.
039	266385-6	TAPPING SCREW 4X14	1	PC.
040	687681-3	STRAIN RELIEF	1	PC.
043	650742-2	SWITCH	1	PC.

046	911233-1	PAN HEAD SCREW M5X20	4 PC.
047	183A33-7	SWITCH HANDLE SET	1
	D10	INC. 35	
A01	152492-0	GRIP 36 COMPLETE	1 PC.
A02	763420-6	CHUCK KEY S13	1 PC.
D01	654593-5	SPLICE	8 PC.