




2019/12
DLM382 1/4


Nr.	Part nr.	Name
001	326636-0	Schakelaarhandel Um104D
002	231876-6	Trekveer 9 Am/Blm
003	911138-5	Schroef 4X20 A
004	455075-8	Hefboom Dlm380
005	455078-2	Schakelarm Dlm380D
007	143510-5	Duwboom (Boven) Am/Blm A
008	459804-1	Schakelaarhuis DLM382
009	233068-3	Drukveer 6Mm Am3643
010	455074-0	Schakelknop Dlm380
011	650730-9	Schakelaar Dhs710
012	687124-5	Klemstrip 9555Nb/Bo3711 A
013	265999-8	Tapschroef 4X25
014	140N15-0	Schakelaarkap DLM382/432
014C10	890374-5	Label Waarschuw Am3643
015	266326-2	Tap Schroef 4X18Mm
016	266326-2	Tap Schroef 4X18Mm
017	456352-1	Schakelhendelhuiskap Am/Blm431
018	456351-3	Schakelhendelhuis Am/Blm431
019	326635-2	Duwboom (Onder) Am/Blm A
020	265A14-4	Moerbout M6X50Mm Am/Blm A
021	264070-5	Sterknop M6 Am/Blm
024	266729-0	Sterknop M8X35Mm Am/Blm
026	459809-1	Kabelhouder DLM382/432
027	660393-3	Draadboom DLM382/432
028	140N21-5	Batterijkap DLM382/432
028C10	8005W1-7	Label waarschuw DLM382
029	890375-3	Label Waarschuw Am3643
030	856L50-3	Naamplaat DLM432
031	856L57-9	Label serienr DLM432
032	8005W9-1	Label indic A DLM382
033	8005W4-1	Label indicatie A DLM432
034	8005W5-9	Label indicatie B DLM432
035	266459-3	Tapschroef Pf 5X25
036	273675-0	Handgreep Blm430/Am3643
037	643890-4	Contactsleutel
038	266326-2	Tap Schroef 4X18Mm
039	183N35-1	Batterijhuis DLM382/432
039C10	263005-3	Rubber Pen 6
040	644809-6	Aansluitunit Djr186
041	183N35-1	Batterijhuis DLM382/432
041C10	263005-3	Rubber Pen 6
042	266326-2	Tap Schroef 4X18Mm
043	127387-6	Maaidekkap DLM432
044	266326-2	Tap Schroef 4X18Mm
045	453250-0	Deblokkeerknop Am/Blm
046	233173-6	Drukveer 4 Uc30/35/4020A

Nr.	Part nr.	Name
047	453251-8	Deblokkeerknopbasis Am/Blm
048	266326-2	Tap Schroef 4X18Mm
049	620B91-3	Lichtcircuit DLM382/432
050	455070-8	Lichtafdekplaat Dlm380D
051	266326-2	Tap Schroef 4X18Mm
053	266774-5	Met.Schr. M6X30Mm Blm430/Am
054	265999-8	Tapschroef 4X25
055	687124-5	Klemstrip 9555Nb/Bo3711 A
056	266326-2	Tap Schroef 4X18Mm
057	638946-6	Draadboom Blm/Am
058	688162-0	Lijn Filter Ub1103
059	688165-4	Lijn Filter Bub360/Bdf453
060	632P19-3	Controller DLM432
060C10	654208-4	Kabelschoen A
061	688162-0	Lijn Filter Ub1103
062	224444-2	Binnenflens 40 Am/Blm
063	191D43-8	Maimes 43cm
064	266731-3	Inbusbout M10X25Mm Am/Blm
065	140S15-0	Uitwerpdeksel DLM382/432
066	961018-5	Stopring E-5
067	259067-7	Uitwerpdekselpen DLM432
068	233597-6	Torsieveer 6Mm Blm/Am
070	459780-9	Maaidek DLM432
070C10	346544-9	Moer M8 DLM382
070C20	931302-2	Zeskantmoer M6
071	412272-9	Onderplaat DLM382/432
072	266326-2	Tap Schroef 4X18Mm
073	231875-8	Trekveer 16 Am/Blm
074	266326-2	Tap Schroef 4X18Mm
075	267102-7	Sluitring 4Mm Blm/Am
076	231297-2	Drukveer 9
077	253808-3	Sluitring 9 Am/Blm
078	266326-2	Tap Schroef 4X18Mm
079	931302-2	Zeskantmoer M6
080	257670-8	Bus 6 Am/Blm
081	453255-0	Stelplaat Blm/Am
082	459099-6	Wisselhendel DLM382
083	921352-5	Inbusbout M6X30Mm Am/Blm
084	346543-1	Koppelstang Blm/Am
085	253414-4	Sluitring 5mm DSP601 A
086	252103-8	Zeskant Borgmoer M5X8 A
087	252145-2	Borgmoer M8 Dcs230T A
088	459101-5	Achterwiel DLM382
089	210070-3	Kogellager 6200Zz Mt903 P
090	165669-8	Achteras Blm/Am
091	346545-7	Montageplaat Blm/Am

Partdrawing for DLM432PT2 - Duwboom



Nr.	Part nr.	Name
092	266326-2	Tap Schroef 4X18Mm
093	252145-2	Borgmoer M8 Dcs230T A
094	459100-7	Voorwiel DLM382
095	210070-3	Kogellager 6200Zz Mt903 P
096	165668-0	Vooras Blm/Am
097	456353-9	Afdekkap Blm430/Am3643
098	266326-2	Tap Schroef 4X18Mm
099	327409-4	Grasvangzakframe DLM432
100	267438-4	Sluitring 5 Am3643
101	266326-2	Tap Schroef 4X18Mm
102	127386-8	Grasvangzak assy DLM432
104	273676-8	Handgreep DLM382
105	459807-5	Deksel DLM432
106	266326-2	Tap Schroef 4X18Mm
107	162680-1	Grasvangzak DLM432
108	459806-7	Grasindicator DLM382
109	224445-0	Buitenflens 40 Am/Blm
110	688238-3	Lijnfilter DLM382/432




Nr.	Part nr.	Name
001	326636-0	Schakelaarhandel Um104D
002	231876-6	Trekveer 9 Am/Blm
003	911138-5	Schroef 4X20 A
004	455075-8	Hefboom Dlm380
005	455078-2	Schakelarm Dlm380D
007	143510-5	Duwboom (Boven) Am/Blm A
008	459804-1	Schakelaarhuis DLM382
009	233068-3	Drukveer 6Mm Am3643
010	455074-0	Schakelknop Dlm380
011	650730-9	Schakelaar Dhs710
012	687124-5	Klemstrip 9555Nb/Bo3711 A
013	265999-8	Tapschroef 4X25
014	140N15-0	Schakelaarkap DLM382/432
014C10	890374-5	Label Waarschuw Am3643
015	266326-2	Tap Schroef 4X18Mm
016	266326-2	Tap Schroef 4X18Mm
017	456352-1	Schakelhendelhuiskap Am/Blm431
018	456351-3	Schakelhendelhuis Am/Blm431
019	326635-2	Duwboom (Onder) Am/Blm A
020	265A14-4	Moerbout M6X50Mm Am/Blm A
021	264070-5	Sterknop M6 Am/Blm
024	266729-0	Sterknop M8X35Mm Am/Blm
026	459809-1	Kabelhouder DLM382/432
027	660393-3	Draadboom DLM382/432
028	140N21-5	Batterijkap DLM382/432
028C10	8005W1-7	Label waarschuw DLM382
029	890375-3	Label Waarschuw Am3643
030	856L50-3	Naamplaat DLM432
031	856L57-9	Label serienr DLM432
032	8005W9-1	Label indic A DLM382
033	8005W4-1	Label indicatie A DLM432
034	8005W5-9	Label indicatie B DLM432
035	266459-3	Tapschroef Pf 5X25
036	273675-0	Handgreep Blm430/Am3643
037	643890-4	Contactsleutel
038	266326-2	Tap Schroef 4X18Mm
039	183N35-1	Batterijhuis DLM382/432
039C10	263005-3	Rubber Pen 6
040	644809-6	Aansluitunit Djr186
041	183N35-1	Batterijhuis DLM382/432
041C10	263005-3	Rubber Pen 6
042	266326-2	Tap Schroef 4X18Mm
043	127387-6	Maaidekkap DLM432
044	266326-2	Tap Schroef 4X18Mm
045	453250-0	Deblokkeerknop Am/Blm
046	233173-6	Drukveer 4 Uc30/35/4020A

Nr.	Part nr.	Name
047	453251-8	Deblokkeerknopbasis Am/Blm
048	266326-2	Tap Schroef 4X18Mm
049	620B91-3	Lichtcircuit DLM382/432
050	455070-8	Lichtafdekplaat Dlm380D
051	266326-2	Tap Schroef 4X18Mm
053	266774-5	Met.Schr. M6X30Mm Blm430/Am
054	265999-8	Tapschroef 4X25
055	687124-5	Klemstrip 9555Nb/Bo3711 A
056	266326-2	Tap Schroef 4X18Mm
057	638946-6	Draadboom Blm/Am
058	688162-0	Lijn Filter Ub1103
059	688165-4	Lijn Filter Bub360/Bdf453
060	632P19-3	Controller DLM432
060C10	654208-4	Kabelschoen A
061	688162-0	Lijn Filter Ub1103
062	224444-2	Binnenflens 40 Am/Blm
063	191D43-8	Maaimes 43cm
064	266731-3	Inbusbout M10X25Mm Am/Blm
065	140S15-0	Uitwerpdeksel DLM382/432
066	961018-5	Stopring E-5
067	259067-7	Uitwerpdekselpen DLM432
068	233597-6	Torsieveer 6Mm Blm/Am
070	459780-9	Maaidek DLM432
070C10	346544-9	Moer M8 DLM382
070C20	931302-2	Zeskantmoer M6
071	412272-9	Onderplaat DLM382/432
072	266326-2	Tap Schroef 4X18Mm
073	231875-8	Trekveer 16 Am/Blm
074	266326-2	Tap Schroef 4X18Mm
075	267102-7	Sluitring 4Mm Blm/Am
076	231297-2	Drukveer 9
077	253808-3	Sluitring 9 Am/Blm
078	266326-2	Tap Schroef 4X18Mm
079	931302-2	Zeskantmoer M6
080	257670-8	Bus 6 Am/Blm
081	453255-0	Stelplaat Blm/Am
082	459099-6	Wisselhendel DLM382
083	921352-5	Inbusbout M6X30Mm Am/Blm
084	346543-1	Koppelstang Blm/Am
085	253414-4	Sluitring 5mm DSP601 A
086	252103-8	Zeskant Borgmoer M5X8 A
087	252145-2	Borgmoer M8 Dcs230T A
088	459101-5	Achterwiel DLM382
089	210070-3	Kogellager 6200Zz Mt903 P
090	165669-8	Achteras Blm/Am
091	346545-7	Montageplaat Blm/Am



Nr.	Part nr.	Name
092	266326-2	Tap Schroef 4X18Mm
093	252145-2	Borgmoer M8 Dcs230T A
094	459100-7	Voorwiel DLM382
095	210070-3	Kogellager 6200Zz Mt903 P
096	165668-0	Vooras Blm/Am
097	456353-9	Afdekkap Blm430/Am3643
098	266326-2	Tap Schroef 4X18Mm
099	327409-4	Grasvangzakframe DLM432
100	267438-4	Sluitring 5 Am3643
101	266326-2	Tap Schroef 4X18Mm
102	127386-8	Grasvangzak assy DLM432
104	273676-8	Handgreep DLM382
105	459807-5	Deksel DLM432
106	266326-2	Tap Schroef 4X18Mm
107	162680-1	Grasvangzak DLM432
108	459806-7	Grasindicator DLM382
109	224445-0	Buitenflens 40 Am/Blm
110	688238-3	Lijnfilter DLM382/432



Nr.	Part nr.	Name
001	326636-0	Schakelaarhandel Um104D
002	231876-6	Trekveer 9 Am/Blm
003	911138-5	Schroef 4X20 A
004	455075-8	Hefboom Dlm380
005	455078-2	Schakelarm Dlm380D
007	143510-5	Duwboom (Boven) Am/Blm A
008	459804-1	Schakelaarhuis DLM382
009	233068-3	Drukveer 6Mm Am3643
010	455074-0	Schakelknop Dlm380
011	650730-9	Schakelaar Dhs710
012	687124-5	Klemstrip 9555Nb/Bo3711 A
013	265999-8	Tapschroef 4X25
014	140N15-0	Schakelaarkap DLM382/432
014C10	890374-5	Label Waarschuw Am3643
015	266326-2	Tap Schroef 4X18Mm
016	266326-2	Tap Schroef 4X18Mm
017	456352-1	Schakelhendelhuiskap Am/Blm431
018	456351-3	Schakelhendelhuis Am/Blm431
019	326635-2	Duwboom (Onder) Am/Blm A
020	265A14-4	Moerbout M6X50Mm Am/Blm A
021	264070-5	Sterknop M6 Am/Blm
024	266729-0	Sterknop M8X35Mm Am/Blm
026	459809-1	Kabelhouder DLM382/432
027	660393-3	Draadboom DLM382/432
028	140N21-5	Batterijkap DLM382/432
028C10	8005W1-7	Label waarschuw DLM382
029	890375-3	Label Waarschuw Am3643
030	856L50-3	Naamplaat DLM432
031	856L57-9	Label serienr DLM432
032	8005W9-1	Label indic A DLM382
033	8005W4-1	Label indicatie A DLM432
034	8005W5-9	Label indicatie B DLM432
035	266459-3	Tapschroef Pf 5X25
036	273675-0	Handgreep Blm430/Am3643
037	643890-4	Contactsleutel
038	266326-2	Tap Schroef 4X18Mm
039	183N35-1	Batterijhuis DLM382/432
039C10	263005-3	Rubber Pen 6
040	644809-6	Aansluitunit Djr186
041	183N35-1	Batterijhuis DLM382/432
041C10	263005-3	Rubber Pen 6
042	266326-2	Tap Schroef 4X18Mm
043	127387-6	Maaidekkap DLM432
044	266326-2	Tap Schroef 4X18Mm
045	453250-0	Deblokkeerknop Am/Blm
046	233173-6	Drukveer 4 Uc30/35/4020A

Nr.	Part nr.	Name
047	453251-8	Deblokkeerknopbasis Am/Blm
048	266326-2	Tap Schroef 4X18Mm
049	620B91-3	Lichtcircuit DLM382/432
050	455070-8	Lichtafdekplaat Dlm380D
051	266326-2	Tap Schroef 4X18Mm
053	266774-5	Met.Schr. M6X30Mm Blm430/Am
054	265999-8	Tapschroef 4X25
055	687124-5	Klemstrip 9555Nb/Bo3711 A
056	266326-2	Tap Schroef 4X18Mm
057	638946-6	Draadboom Blm/Am
058	688162-0	Lijn Filter Ub1103
059	688165-4	Lijn Filter Bub360/Bdf453
060	632P19-3	Controller DLM432
060C10	654208-4	Kabelschoen A
061	688162-0	Lijn Filter Ub1103
062	224444-2	Binnenflens 40 Am/Blm
063	191D43-8	Maaimes 43cm
064	266731-3	Inbusbout M10X25Mm Am/Blm
065	140S15-0	Uitwerpdeksel DLM382/432
066	961018-5	Stopring E-5
067	259067-7	Uitwerpdekselpen DLM432
068	233597-6	Torsieveer 6Mm Blm/Am
070	459780-9	Maaidek DLM432
070C10	346544-9	Moer M8 DLM382
070C20	931302-2	Zeskantmoer M6
071	412272-9	Onderplaat DLM382/432
072	266326-2	Tap Schroef 4X18Mm
073	231875-8	Trekveer 16 Am/Blm
074	266326-2	Tap Schroef 4X18Mm
075	267102-7	Sluitring 4Mm Blm/Am
076	231297-2	Drukveer 9
077	253808-3	Sluitring 9 Am/Blm
078	266326-2	Tap Schroef 4X18Mm
079	931302-2	Zeskantmoer M6
080	257670-8	Bus 6 Am/Blm
081	453255-0	Stelplaat Blm/Am
082	459099-6	Wisselhendel DLM382
083	921352-5	Inbusbout M6X30Mm Am/Blm
084	346543-1	Koppelstang Blm/Am
085	253414-4	Sluitring 5mm DSP601 A
086	252103-8	Zeskant Borgmoer M5X8 A
087	252145-2	Borgmoer M8 Dcs230T A
088	459101-5	Achterwiel DLM382
089	210070-3	Kogellager 6200Zz Mt903 P
090	165669-8	Achteras Blm/Am
091	346545-7	Montageplaat Blm/Am

Nr.	Part nr.	Name
092	266326-2	Tap Schroef 4X18Mm
093	252145-2	Borgmoer M8 Dcs230T A
094	459100-7	Voorwiel DLM382
095	210070-3	Kogellager 6200Zz Mt903 P
096	165668-0	Vooras Blm/Am
097	456353-9	Afdekkap Blm430/Am3643
098	266326-2	Tap Schroef 4X18Mm
099	327409-4	Grasvangzakframe DLM432
100	267438-4	Sluitring 5 Am3643
101	266326-2	Tap Schroef 4X18Mm
102	127386-8	Grasvangzak assy DLM432
104	273676-8	Handgreep DLM382
105	459807-5	Deksel DLM432
106	266326-2	Tap Schroef 4X18Mm
107	162680-1	Grasvangzak DLM432
108	459806-7	Grasindicator DLM382
109	224445-0	Buitenflens 40 Am/Blm
110	688238-3	Lijnfilter DLM382/432