






Parts Breakdown

PJ7000

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	922422-3	H.S.H. BOLT M8X16, PJ7000	2
2	941202-8	F. WASHER 8, BPB180	2
3	453218-6	GRIP, PJ7000	1
4	266324-6	TAPPING SCREW 4X22, GA4030	4
5	417771-6	PIN CAP, 9557NB	1
6	234057-1	COMPRESSION SPRING 8, GA4030	1
7	252186-8	HEX. NUT M6, GA4030	1
8	227545-5	SPIRAL BEVEL GEAR 10, GA4030	1
9	213445-5	O-RING 26,9557NB	1
10	211092-6	B. BEARING 629DDW, BO4556	1
11	962105-3	RETAINING RING R-26, GA4530	1
12	413126-3	GUIDE PLATE, GA4030	1
13	240139-9	N/A	1
	240107-2	FAN 56, GA4030	
14	517646-0	ARMATURE ASS'Y, GA4530	1
15	681636-0	INSULATION WASHER, GA4030	1
16	210034-7	BALL BEARING 607LLB, BO4556	1
17	421868-5	LABYRINTH RUBBER RING, GA4030	1
18	450796-7	BAFFLE PLATE, GA4030	1
19	266325-4	TAPPING SCREW 4X70, GA4030	2
20	623531-8	FIELD, GA4030	1
21	896483-8	NAME PLATE, PJ7000	1
22	266492-5	TAPPING SCREW 3X8, GA4534	2
23	643839-4	BRUSH HOLDER 6X9, GA4030	2
24	CB458	CARBON BRUSH SET, 195025-8	1
	195025-8	CARBON BRUSH SET, 195025-8	
25	650621-4	SWITCH PS-10, GA4030	1
26	687681-3	STRAIN RELIEF, GA4030	1
27	266326-2	TAPPING SCREW PT 4X18, 5007MG	1
29	682502-4	CORD GUARD 8-85, HP2010N	1
30	664064-4	CORD (2X18X8 SJ), BO4556	1
31	266326-2	TAPPING SCREW PT 4X18, 5007MG	1
32	450794-1	REAR COVER, GA4030	1
33	450797-5	SWITCH LEVER, GA4030	1
34	233121-5	COMP. SPRING 4, GA4030	1
35	141325-4	MOTOR HOUSING CPL., PJ7000	1
36	419566-3	SWITCH KNOB, GA4030	1
37	213032-0	O-RING 4, GA4534	1
38	256510-7	SHOULDER PIN 4, GA4030	1
39	141327-0	GEAR HOUSING CPL., PJ7000	1
40	210033-9	BALL BEARING 696ZZ, GA4030	1
41	233950-6	RING SPRING 11, GA4030	1
42	227546-3	SPIRAL BEVEL GEAR 37, GA4030	1
43	962151-6	RETAINING RING R-32, 9005B	1
44	211129-9	BALL BEARING 6201DDW, GA4030	1
45	326120-5	SPINDLE, PJ7000	1
46	213561-3	O RING 42, GA4030	1
47	318811-2	BEARING BOX, PJ7000	1
48	911136-9	P.H. SCREW M4X20, PJ7000	4
50	931203-4	HEX NUT M5, PJ7000	1
51	266741-0	PAN HEAD SCREW M5X50, PJ7000	1
52	453406-5	BASE COVER, PJ7000	1
53	326145-9	ROD 10, PJ7000	2
54	141247-8	FENCE CPL., PJ7000	1
55	961017-7	STOP RING E-3, HR2475	2
56	256689-4	PIN 4, PJ7000	2
57	318813-8	BASE, PJ7000	1
58	231282-5	COMP. SPRING 2.4, PJ7000	1



Parts Breakdown

PJ7000

59	216001-0	STEEL BALL 3.5, LXDT08	1
60	318814-6	STOPPER, PJ7000	1
61	266264-8	H.S.H.SCREW M5X8, LS1016L	2
62	266738-9	+ PAN HEAD SCREW M4, PJ7000	1
63	213008-7	O RING, LXRH01	1
64	415252-4	DUST NOZZLE, PJ7000	1
65	265785-7	THUMB SCREW M5X10, KP0800K	1
66	232131-9	LEAF SPRING, PJ7000	1
67	213023-1	O RING 4, PJ7000	1
68	266737-1	FLAT HEAD SQ. NECK BOLT M6X20, PJ7000	1
69	231282-5	COMP. SPRING 2.4, PJ7000	1
70	216001-0	STEEL BALL 3.5, LXDT08	1
71	231795-6	TENSION SPRING 8, PJ7000	2
72	272263-0	LEVER 40, PJ7000	1
73	252159-1	HEX. NUT M6, BCS550	1
74	961014-3	STOP RING E-8, BSS501	1
75	253804-1	F. WASHER 6, LS1016L	1
76	224280-6	INNER FLANGE, PJ7000,3901	1
77	224505-8	LOCK NUT 10-40, PJ7000,3901	1
78	318845-5	BLADE COVER, PJ7000	1
79	424479-5	RUBBER SPIKE, PJ7000	2
80	213023-1	O RING 4, PJ7000	1
	123148-2	ANGLE GUIDE ASS'Y, PJ7000	1
	123150-5	DUST BAG ASSEMBLY, PJ7000, 3901	1
	415579-2	SET PLATE 4, PJ7000, 3901	1
	A-95118	4 CARBIDE CUTTER, 3901 PJ7000	1
	782401-1	LOCK NUT WRENCH, PJ7000	1
	821509-7	PLASTIC TOOL CASE, PJ7000	1